

### Product Use and Design

**Foam-Lok FL 2100 LE** is a closed-cell spray applied foam using Environment Canada's approved next generation blowing agent. The foam is tinted orange to signify our **FL 2100 LE** Canada spray insulation product line. When installed following application guidelines the spray foam insulation adheres tenaciously to framing members and substrates. **FL 2100 LE** closed-cell spray foam provides superior energy economy and durability while significantly reducing unmanaged moisture and air infiltration.

### Product Use

As a component of a "systems approach" to proper building envelope construction, **FL 2100 LE** closed-cell spray foam provides exceptional performance in reducing heat transfer, moisture gain and significantly improving racking strength.

### Recommended Processing Parameters

Processing Designation:	Regular
Winter:	-6°C - +10°C ( 20°F - 50°F)
Regular:	10°C - 27°C (50°F - 80°F)
Summer:	27°C ( 80°F - and above )

Optimum hose pressure and temperature may vary as a function of the type of equipment, ambient and substrate conditions, and the specific application. It is the responsibility of the applicator to properly interpret equipment technical literature, particularly information that relates acceptable combinations of gun chamber size, proportioner output, and material pressures.

Processing Designation:	FL 2100 LE
Equipment Dynamic Pressure	1,000 - 1,400 psi
Preheat Temperature	52°C - 57°C (125°F - 135°F)
Hose Heat Temperature	52°C - 57°C (125°F - 135°F)
Drum Temperature Storage	15°C - 30°C (60°F - 86°F)

### Material Shelf Life:

Twelve (12) months when stored within recommended temperature range.

### Physical Properties

Properties	Test Method/ Requirements	Value per CAN/ULC S705.1
Initial Thermal Resistance at 50 mm	ASTM C518	2.4 (m <sup>2</sup> ·K)/W (R14 at 2")
Conditioned Thermal Resistance at 50 mm	ASTM C518	2.3 (m <sup>2</sup> ·K)/W (R13 at 2")
LTTR Value at 50mm:	CAN/ULC S770	2.02 (m <sup>2</sup> ·K)/W (R12 at 2")
Compressive Strength	ASTM D1621	262 kPa
Tensile Strength:	ASTM D1623	283 kPa
Core Density:	ASTM D1622	38.2 kg/m <sup>3</sup> ! \$2%+ TIX%
Open Cell Content:	ASTM D6226	2%
Air Permeance at 35mm:	ASTM E2178	<0.0005 L/s.m <sup>2</sup>
Water Vapour Permeance at 50mm:	ASTM E96	34 ng/(Pa·s·m <sup>2</sup> ) (0.6 perm at 2")
Dimensional Stability:	ASTM D2126 -20°C 80°C 70°C @ 97% RH	-0.1 -0.5 +12.1
Water Absorption:	ASTM D2842	0.6%
Flame Spread:	CAN/ULC S127	340
Smoke Development:	CAN/ULC S102	325
F <sub>1</sub> V <sub>1</sub> Fa <sub>1</sub> ZA U <sub>1</sub> gbS <sub>1</sub> Uk	CAN/ULC-S774	A <sub>1</sub> W <sub>1</sub> #f <sub>1</sub> bSkf <sub>1</sub>
Fungus Testing	ADTM C 1338	No Growth

\* Fad dVcaXf La` efdUfja` d fZWfL Wfa aUgbs` Uk [e a` W#fi VSk i ZW fZWeWdVSfW dVcaXf SdW[e hVf[SfW Se dVg[dW Tk 53@!G>5E) "" 2 Vgd Y [ eS^Sf[a` aXfZWbcaVgUfz

### Evaluation Services

- **CCMC 14105-L**
- **CAN/ULC S705.1-1**
- 2:1 transfer pumps are recommended for material transfer from container to the proportioner.
- CAUTION: Extreme care must be taken when removing and reinstalling drum transfer pumps so as NOT to reverse the "A" and "B" components.
- Do not circulate or mix other suppliers' "A" or "B" component into **FOAM-LOK™** containers.
- The plural component proportioner must be capable of supplying each component within ± 2% of the desired 1:1 mixing ratio by volume.

# FOAM-LOK™

## SPRAY FOAM INSULATION

 **FOAM-LOK™ FL 2100 LE**  
Closed-Cell Spray Insulation  
CCMC 14105-L  
CAN/ULC S705.1-01  
Rev. Date 09/21/2018

**THIS FOAM MUST NOT BE APPLIED IN EXCESS OF 50 mm (2.0 INCHES) PER APPLICATION. THE FOAM SHOULD BE ALLOWED TO COOL FOR 20 TO 30 MINUTES OR UNTIL THE SURFACE TEMPERATURE HAS RETURNED TO AMBIENT BEFORE ADDITIONAL APPLICATIONS OF FOAM ARE ATTEMPTED. FOAM APPLIED IN EXCESS OF 50 mm (2.0 INCHES) OR WITHOUT ALLOWING FOR COOLING MAY RESULT IN, BUT IS NOT LIMITED TO, EXCESS HEAT BUILD-UP AND RESULT IN FIRE OR THE GENERATION OF OFFENSIVE ODORS THAT MAY NOT DISSIPATE WITH TIME.**

### Thermal Barrier

The **FL 2100 LE** shall be installed in accordance with the National Building Code of Canada and CAN/ULC-S705.2. The National, Provincial and Local building codes require that SPF be separated from the interior of a building by an approved fifteen (15) minute thermal barrier, such as 1/2" gypsum wall board or equivalent, installed per manufacturer's instructions and corresponding code requirements. There are exceptions to the thermal barrier requirement: (1) Code authorities may approve coverings based on fire tests specific to the SPF application. For example, covering systems that successfully pass large scale tests may be approved by code authorities in lieu of a thermal barrier; (2) SPF protected by 1" thick masonry does not need a thermal barrier. Applicators should ensure the safety of the jobsite and construction personnel by posting appropriate signs warning that all "hot work" such as welding, soldering, and cutting with torches should take place no less than 35 feet from any exposed foam. If "hot work" must be performed all spray polyurethane foam should be covered with an appropriate fire or welder's blanket, and a fire watch should be provided.

### Handling and Safety

Respiratory protection is **MANDATORY!** Lapolla requires that supplied air and a full face mask be used during the application of any spray applied foam system. Contact Lapolla Industries for a copy of the Model Respiratory Protection Program developed by CPI or visit their web site at [www.polyurethane.org](http://www.polyurethane.org). Persons with known respiratory allergies should avoid exposure to the "A" component. The "A" component contains reactive isocyanate groups. The materials must be handled and used with adequate ventilation. The vapors must not exceed the TLV (0.02 parts per million) for isocyanates. Avoid breathing vapors. Wear a NIOSH approved respirator. If inhalation of vapors occur, remove victim from contaminated area and administer oxygen if breathing is difficult. Call a physician immediately. Avoid contact with skin, eyes, and clothing. Open containers carefully, allowing any pressure to be relieved slowly and safely. Wear chemical safety goggles and rubber gloves when handling or working with these materials. In case of eye contact, immediately flush with large amounts of water for at least fifteen minutes. Consult a physician immediately. In case of skin contact, wash area with soap and water. Wash clothes before reuse.

Applicators should ensure the safety of the jobsite and construction personnel by posting appropriate signs warning that all "hot work" such as welding, soldering, and cutting with torches should take place no less than 35 feet from any exposed foam. If "hot work" must be performed all spray poly-urethane foam should be covered with an appropriate fire or welder's blanket, and a fire watch should be provided.

The potential results of improperly applied materials may include but is not limited to, excessive heat build-up, and may result in a fire or offensive odors which may not dissipate with time and/or poor product performance due to improper density of the applied material. Large masses of sprayed materials should be avoided. When large masses are generated they should be removed from the area, cut into small pieces and allowed to cool before disposal. Failure to follow this recommendation may result in a fire. It is recommended that a fire extinguisher be located in an easily accessible portion of the work area.

### In Case of Spills or Leaks

- Utilize appropriate personal protective equipment
- Ventilate area to remove vapors
- Contain and cover spilled material with a loose, absorbent material such as oil-dry, vermiculite, sawdust or Fuller's earth
- Shovel absorbent waste material into proper waste containers
- Wash the contaminated areas thoroughly with hot, soapy water
- Report sizeable spills to proper environmental agencies

### In Case of Fire

**Extinguishing Media:** Dry chemical extinguishers such as mono ammonium phosphate, potassium sulfate, and potassium chloride. Additionally, carbon dioxide, high expansion (proteinic) chemical foam, or water spray for large fires.

Positive pressure ventilation of the work area is recommended to minimize the accumulation of vapors in the work area during the application. Improper application techniques of this foam system must be avoided. This includes excessive thickness, off ratio material, and spraying into rising foam. The potential results of improperly applied materials may include but is not limited to excessive heat build-up, and may result in a fire or offensive odors which may not dissipate with time and/or poor product performance due to improper density of the applied material. Large masses of sprayed materials should be avoided. When large masses are generated they should be removed from the area, cut into small pieces and allowed to cool before disposal. Failure to follow this recommendation may result in a fire. It is recommended that a fire extinguisher be located in an easily accessible portion of the work area.

### DISCLAIMER

The data presented herein is not intended for use by non-professional applicators, or those persons who do not purchase or utilize this product in the normal course of their business. The potential user must perform any pertinent tests in order to determine the product's performance and suitability in the intended application, since final determination of fitness of the product for any particular use is the responsibility of the buyer.

All guarantees and warranties as to products supplied by Icynene-Lapolla shall have only those guarantees and warranties expressed in writing by the manufacturer. The buyer's sole remedy as to any material claims will be against the applicator of the product. The aforementioned data on this product is to be used as a guide and is subject to change without notice. The information herein is believed to be reliable, but unknown risks may be present.

**NO WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING PATENT WARRANTIES OR WARRANTIES OF MERCHANTABILITY OR FITNESS FOR USE, ARE MADE BY LAPOLLA WITH RESPECT TO OUR PRODUCTS OR INFORMATION SET FORTH HEREIN.**

